



Odd Ball Industries Mfg. Co., Inc.
PO Box 376 · Greenlawn, NY 11740
Ph: (631) 754-0400 / Fx: (631) 925-5347
www.oddballindustries.com

Installation of SP-3 Grab Bar

Warning: This product is ligature-resistant only when properly installed. A loosened fixture can easily be tied to. Any product which can be removed can be used as a weapon!

Directions:

1. Secure to the wall using 1/4-20 fasteners¹ through the mounting holes in the flanges. (Fasteners not included.) Grab bars are supports, and therefore require adequate anchoring into a structurally sound wall.
2. For grab bars longer than 48":
 - Stainless steel clips are provided, each with two holes
 - Secure the clip to the fin of the grab bar using an 8-32 tamper proof¹ round head machine screw (not included) through the smaller hole.
 - Secure the clip to the wall using a 1/4-20 fastener¹. (Fastener not included.)
3. Verify that the grab bar cannot be loosened or removed.
4. Verify that there are no gaps large enough to accommodate a tie. Any such gaps must be filled with a security sealant (such as Pecora Dynapoxy EP-1200).

Note: Gaps are permissible for drainage of water if they are too small to accommodate a tie.

Note: This grab bar is designed for horizontal installation only.

Maintenance: Only clean with mild detergent and a non-abrasive cloth. Aggressive cleaning techniques may remove the finish.

¹ Tamper proof fasteners are strongly recommended. The selection of a particular size and type of tamper proof fastener should be made in conjunction with a facility manager, because it depends upon factors such as construction materials and institutional standards.



Odd Ball Industries Mfg. Co., Inc.
PO Box 376 · Greenlawn, NY 11740
Ph: (631) 754-0400 / Fx: (631) 925-5347
www.oddballindustries.com

